MEC I-BAR SHRINK SYSTEM WITH HEAT GUN



Vector Contour

While a variety of Centerfold Films can be used with the machines we recommend CONTOUR Brand POF Films for the best result. These FDA Food Grade Films are available in various Sizes & Thicknesses and can be Shrink wrapped.

Model	Seal	Seal	Power	Heat
Type	Length	Type		Gun
ME450SPT	450mm	1mm Cut Wire	240V/50Hz 350W	1500W
ME600IPT	600mm	1mm Cut Wire	240V/50Hz 450W	



According to the micron of the film set the **control dial** (inset) between 5 and 8. Place the roll of **POF centerfold film** on the **rollers**.



Part it with the **separating plate** and pull a length under the **sealing arm**. Press the sealing arm down to seal the film closed.



Pull a length of film out and insert the **product** between the two pieces of film



Press the **sealing arm** firmly down and hold until the red light switches off. The sealed product should pull away easily.



Rotate and repeat the sealing on the open side ,tearing the excess plastic away as the sealing light switches off.



Apply the **heat gun** to all sides of the product. The heat will shrink the film firmly around the product.

Call 031 5693056

for sales and assistance email sales@mipaq.co.za

Click www.mipaq.co.za

to visit our online world for product catalogues, product support and the latest news ...

